Soft Absorber


Bellofram Seal Type Dashpot Structure

FA-1212C Series

RoHS Compliant

Products specification might be changed without notice.





Specifications

Model	Max. absorption energy J (kgf•m)	Speed range m/s	Max. equivalent mass kg (kgf)	Max. drag N(kgf)	Absorption energy per minute J/min (kgf·m/min)	Max. cycle rate cycle/min	Rod cap colour
FA-1212C1-C	0.29(0.03)		1.5(1.5)	245 (25)	14.7(1.5)	45	White
FA-1212C2-C	0.49 (0.05)	0.1~1.0	3(3)		14.7(1.5)	45	Black
FA-1212C3-C			5(5)	294(30)			Yellow
FA-1212C4-C	1.0 (0.10)	0.1~0.7	7.5 (7.5)	294(30)	5.0 (0.5)	5	Green
FA-1212C5-C		0.1~0.5	10(10)				Red

Common Specifications

Stroke	mm	12
Recovering power of the piston rod	N (kgf)	2.45 (0.25) or less
Operating temperature	${\mathbb C}$	-10~50
Mass	g	15
Main unit material		Resin

Precautions for Use

- * Do not use this product without carefully reading the attached owner's manual.
- * Use with an external stopper.
- * Ensure that sufficient mounting strength is secured for this product. (As a guideline, it should be 2 to 3 times the maximum drag listed in the catalogue.)
- * Do not turn the oil inlet screw located at the bottom of the main unit.
- * 2 or more of this product can be used in parallel.


- * Do not use this product in a vacuum or a location where it may come in contact with oil.
- * Ensure that an eccentric load is not applied to the soft absorber. (Allowable eccentric angle: within ±2.5°)
- * Do not over-tighten the main unit and nuts. Please use the tightening torque (1.5N·m) listed in the owner's manual. If anchoring the absorber against the Ø14.6 unit, please use a tightening torque of 1.0N·m.

Optional Parts

Muting cap OP-090-M12B/C/D Model OP-090-M12B OP-090-M12C OP-090-M12D B : Black [□] A muting cap reduces the $\mathsf{C}:\mathsf{White}$ collision noise.

To use, place it over a rod cap in the FA-1212C series.


•Stroke length is 11mm.



Small hexagon nut M12B

Model M12B

• It is ideal for tight spaces, as it is smaller than the conventional hexagon nuts.



Standard nuts are sold separately as well.

Applicable Models	Model
FA-1212C	FA-1212C nut

Bellofram Seal Type Single Orice Structure

Fixed Type Adjustable type Self-adjusting

RoHS Compliant


•Products specification might be changed without notice.

Optional Parts

Muting cap OP-090-M12B/C/D

Model		
OP-090-M12B		
OP-090-M12C		
OP-090-M12D		


- A muting cap reduces the collision noise.
- To use, place it over a rod cap in the FA-1212L series.
- Stroke length is 11mm.



Small hexagon nut M12B

Model M12B

• It is ideal for tight spaces, as it is smaller than the conventional hexagon nuts.



The standard nut is also sold separately.

Applicable Models	Model				
FA-1212L	Nut for FA-1212C				